



THRIVE
AGRITECH

(800) 205-7216
thriveagritech.com
info@thriveagritech.com



Infinity XE

LED Light Bar


DIMMING

0-10V dimming from max intensity to off.



WIRING & INTERCONNECTION

Infinity XE LED light bars can be electrically connected end-to-end or with an interconnection cable. See the installation manual for detailed instructions.




MAXIMUM DAISY-CHAIN


Voltage	Max # of connected	Current/Fixture
120	14	0.54 A
240	31	0.25A
277	35	0.22A

MOUNTING

FLUSH MOUNT



SUSPENSION MOUNT



LIGHTING LAYOUTS

Lighting layouts for a variety of horticulture applications are available, if you need a customized lighting layout please contact our customer support team. (800) 205-7216 • thriveagritech.com • info@thriveagritech.com

